



Printer calibration page, A4

Print this on plain paper, not on labels.

1. Print at Actual size (100%). Turn off Fit to page, Fit to paper and Fit to printable area.
2. Set the paper size to A4 in the print dialog and in the printer settings.
3. Measure with a ruler. The numbers below are what a correct print measures.

Scale (is the page resized?)

The bar along the top is 180 mm long and the bar down the left is 200 mm.
If a bar is clearly shorter or longer, the page was resized: fix the scale and paper size first.
Off by 1 mm or less with the settings right? Your printer may stretch the page a little:
see the stretch correction in the guide on misaligned labels at taskivator.com/peelstack.

Position (where does the printer put the page?)

The centre of each cross is 12.7 mm (1/2 inch) from the two paper edges next to it.
Measure from the left edge and from the top edge to the top left cross, in mm. Then:
offset X = 12.7 minus the left distance, offset Y = 12.7 minus the top distance (mm).
Plus moves the print right or down, minus moves it left or up. In Peelstack Label Maker open
"Labels print a little off? Align your printer" and type the two numbers as they are:
its box is in mm for A4.

Crosses missing or cut off?

Crosses missing, or not 12.7 mm from their edge on one side only? Check the paper size first:
it must match the paper in the tray, in the print dialog and in the printer settings.
If the paper size is right, your printer cannot print that close to the edge.
Then measure a bar that prints in full, or the distance between ruler marks you can see.

Peelstack Label Maker, taskivator.com/peelstack

